



Automated Fire on the Water Surface Installation Instructions

Automated "Fire on Water Surface" System Overview




Pilot Burner / Submersible Manifold Detail



2 PSI Min. Required

Pilot Burner Vertical Positioning

The Pilot Burner for the Fire on Water Surface system is shown in the photo at right. The blue line indicates the desired water level in relation to the Pilot Burner Wind Cap. The water level can be at the blue line or as low as 1/2" below the blue line.



**Plumbing Transition for Gas Lines
in Fire on Water Surface Feature
(Assuming 2" PVC sleeve installed)**

